APPENDIX RA-6

SIGHT GAGES - CLOSED CIRCUIT

G601 SERIES - INSTALLATION INSTRUCTIONS

- 1. For thin wall tank, drill two .34 inch (8.6mm) diameter holes in tank wall corresponding to centerline of gage -OR- drill and tap tank wall to mate with selected mounting bolt and centerline of gage. The acceptable tolerance between drilled mounting holes is [+/- .03 inch (+/-0.8 mm)]
- 2. Remove burrs from holes to provide good sealing surfaces.
- 3. Verify o-rings are set properly in recess provided on backside of gage body and under the head of the mounting bolt.
- 4. Install gage by first tightening the mounting bolts by hand until secure.
- 5. Then using a torque wrench, uniformly tighten mounting bolts to 11 in-lbs (1.24 N-m).

NOTE: The tank seal is designed to space the gage body away from the tank wall. Excessive assembly torque may cause the tank seal to fail prematurely.

sales@ldi-industries.com